



48	Spanner				
47	Brush hold	31	Rubber sleeve	16	Bearing
46	Brush hold	30	Bearing	15	Circlip
45	Screw	29	Stator	14	Wave spring washer
44	Screw	28	Rotor	13	Screw
43	Screw	27	Circlip	12	Gear
42	Left handle	26	Screw	11	Screw
41	Spring	25	Bearing	10	Bearing
40	Cord	24	Baffle	9	Front cover
39	switch	23	Gear	8	Scaw cap
38	capacitance	22	Nut	7	Screw
37	Right handle	21	Gear housing	6	Wheel cover
36	Cable clamp	20	Abor	5	Spindle shaft
35	Spring	19	Spring	4	Key
34	Housing	18	Handle	3	Inner flange
33	Cover	17	Circlip	2	Grinding wheel
No.	PART NAME	No.	PART NAME	No.	PART NAME

Explosive view

S1M-JC8-